

**AA-11-05258**  
**WATERPLACE 20" BIRCH HD LOG SET**  
**INSTALLATION INSTRUCTIONS**



**Caution:** The log pieces are fragile. Exercise extreme care when opening the log set package and removing individual log pieces.

**Note:** In order to install the log set in the 60" Waterplace both the 20" and 40" log sets are needed.

# NETZERO FIRE

## Included Logs

Open the packaging and remove the logs. Use the guide below to identify the logs.



35-01-02029 LEFT LOG



35-01-02030 RIGHT LOG



35-01-02031  
FRONT LOG

# NETZERO FIRE

## Installation Instructions

This log set is for use with the 20" Waterplace burners. The log set can also be used with the Waterplace 40" Birch HD Log Set to cover the 60" Waterplace burners. Follow the instructions included with the Waterplace 40" Birch HD Log Set when installing the log set on the 60" Waterplace burners.

The log set must be placed on the burner as shown in these instructions. The logs have been designed to allow the mist from the burner to rise around the logs. Failure to correctly place the logs can result in poor burner performance.

It is important to follow all recommendations in the burner manual for the quality of water used in the burner. If excessively hard water is used in the burner calcium deposits may form on the logs and burner. The logs can be cleaned with a soft brush to remove any deposits.

1)

Place the left-side log across the burner as shown in the photo below. The bottom of the log is flat and will allow the log to sit on the burner.



# NETZERO FIRE

2)

Place the right-side log on the burner as shown. The log will rest in the notch on the top of the left-side log. Make sure the log is rotated so that the flat part on the end of the log is sitting on the burner top.



Place the front log as shown so that it is resting in the notch on the right-side log. The installation is then complete.

